Leapfrog
3D Printers

My print bed doesn't heat up



***Your bed most likely does reach the correct temperature but due to insulation the thermistor displays a lower value for the temperature.**

You can contact support at support.lpfrg.com